









































Šatní skříň 180 se zrcadlem ROXY









	T3  1760mm x4	G3  4x30 x1	T30  x1	S1  1620mm x1
T1  x8	T2  x4	L3  x4	K6  x2	K1  ø15x12 x16
S2  x34	W1  x5	E6  x2	G6  3x13 x36	K15  x12
S5  866mm x2	P3  x8	G8  4x30 x4	G2  3x20 x100	G4  4x16 x17
A1  ø7x50 x42	B7  ø8x30 x96	W2  x1	M2  x4	S4  x4




I










IV



V



VI



VII

